


**WHAT'S IN THE BOX**




Speaker connector x 4



12V Trigger connector x 1



Input/output connector x 10



Mains AC cord x 2



Feet x 4




Screws x 4

**NOTES**

- Download the latest A860 Owner's manual from the Manuals/Downloads tab of [www.bluesoundprofessional.com/product/A860](http://www.bluesoundprofessional.com/product/A860)
- Visit [support.bluesound.com](http://support.bluesound.com) for further assistance and information about getting the most out of the A860.

**CONNECT**


**SPEAKER WIRES TO SPEAKER CONNECTOR AND INSTALL TO A860**



**NOTE:** Connected speakers are for illustration purposes only. Speakers to be connected are dependent upon availability.


**CONNECT**

**ANALOG SOURCE USING GLOBAL INPUT**




# CONNECT

## ANALOG SOURCES USING LOCAL INPUT



**NOTE:** The number of sources are for illustration purposes only. Sources to be connected are dependent upon availability.

# POWER UP!



**NOTE:** Adjust corresponding Gain control of active Global or Local inputs.